







WHAT'S IN THE BOX






























USB Type-C Cable






THE BOTTOM

INSTALLATION



The optimal operating range between the receiver and the keyboard is 30 to 100 cm,




ensuring there are no obstructions between them.

Connect to a Desktop Computer



2 Connect to the Laptop Computer






Flash Light

F10

Note: To re-enter pairing mode, long press "Fn + F10" for 3 seconds.

**CONNECTING 2.4G DEVICE** 

F9



DEVICES

Choose [WS98] from

your Bluetooth device.



The F11 key will light up for 10 seconds, indicating that

the 2.4G device is connected.

(USB)

Solid Light

F10

F9

4 \*1 The F9 key will

light up for a while

then light off after the keyboard is connected.




Insert the nano receiver

into your computer's USB port.

Re-Pairing: Long Press

[Fn+F10] for 3s



1 Attach the Type-C end to the

keyboard and the USB end

to your computer.

First Pair: Automatic Pairing Re-Pair: Short-Press for 3S

ALT

ALT

ALT

ALT

CTRL




Bluetooth

Pairing: Flashes Slowly Connected: Solid Light 10S

2 Turn on the keyboard

power switch.

**Note:** The factory default mode is 2.4G. If the keyboard does not function,



2.4G Device

Option ~

Command \*\*

Command #

Option ~



**USB** Wired

F12 Key Flash Light

F12 Solid Light 10S

No Need to Pair

(FN)


Light 109



**COMBINATION FN KEYS** 

Bluetooth

INDICATOR (For Mobile Phone/Tablet/Laptop)



Start ==

Alt-Right

Ctrl-Right

HOW TO CONFIRM CURRENT DEVICE

the F9~F12 keys will light up to show the currently connected devices.

Alt

**WIRELESS K-ESPORT EDITOR** 

Provide the keyboard with simple combination settings and programming

Solid Red: Charging

Use the keycap puller to remove the keycaps.

Insert the switch into the


PCB and secure it.

■ No Light: Fully Charged ≤10H Charging Time

**SWAP SWITCH STEP** 

Compatible with 3-Pin & 5-Pin Style Mechanical Switches





Light Off: about 666 Hours

Note: While the keyboard is connected with Bluetooth or 2.4G wireless mode, if you plug in the Type-C cable to the keyboard, the wired mode is for charging only. The keyboard will not automatically


[11]

\*Flashing red light indicates when the batteryis below 15%.

switch to wired mode.

Line up the switch pins with the PCB socket.

Put the keycaps back on the keyboard and test it.



the same environment?

2. Ensure the wireless environment is within 30~100 cm, with no obstacles or metal objects. 3. Check for strong wireless routers or other wireless transmitter interference sources within 1 meter.

(Answer) We recommend 10 units or less. (For more than 10 units, it is recommended to be 1.5m~3m apart)

Question Is there a maximum number of wireless products that can be used in

Question Does the keyboard support Win/Mac platforms and also Android

(Answer) Yes, the layout of the Android platform is the same as the Win platform,

Answer No, multi-mode devices need to be switched manually.

**TECH SPEC** 

**Operating Range**:

**Bluetooth Version:** 

Type-C Cable Length:

System Requirements:

**Anti-Interference Extension Dock:** 

**WARNING STATEMENT** 

damage due to lithium battery leakage. 2. Avoid exposing to strong sunlight.

Connection:

Multi-Device:

Layout:

Use the switch puller to remove the switches.

Gently press the switch





1. Disassembling, bumping, crushing, or throwing into the fire can cause irreparable

Bluetooth / 2.4G / Wired

4 Devices (Bluetoothx2, 2.4Gx1, USBx1)

5-10 M Bluetooth v5.1

180 cm

120 cm Windows 10 / 11

Windows | Mac

3. Follow local laws for battery disposal; recycle if possible. Improper disposal may cause fire or explosion. 4. Avoid charging in environments below 0°C. 5. Do not remove or replace the battery.

The following actions may cause damage to the product:

- 6. Do not use chargers with outputs from 6V to 24V. Use a 5V charger to avoid damage.







www.Bloody.com